

Eliminate The Risk Of Drops And Injury And Speed-up Fit Times When Installing External A/C Condensers With The Outdoor Split Hoist...

This new product is available exclusively with MEP Hire and has been designed to improve your safety provision, whilst increasing your productivity.

The **Outdoor Split Hoist** enables you to fit outdoor A/C Condenser type units to external walls, eliminating the need for manual lifting and handling.

The weight of the unit being fitted is supported effortlessly by the hoist, making it easy for a single engineer to fix it into place.



CONTACT MEP HIRE

T: 0800 587 5121 E: hire@mephire.co.uk W: www.mephire.co.uk



HOW IT WORKS...

- CLAMP
 Simply attach the Outdoor Split Hoist to the external wall bracket.
- **2 ATTACH**Use the straps to fit your unit to the hoist.
- Using a cordless drill, steadily hoist your unit into position.
- Fix your unit into place. Then undo the straps and remove the hoist from the stud supports.

SPECIFICATIONS

- Attaches to the wall bracket of the A/C Condenser Unit
- Portable and lightweight (comes in a carry bag)
- Lifts up to 4 metres in height
- Supports weights of up to 100 kg
- Operated by cordless drill; 19mm socket ¼ inch drive adaptor
- One person operation
- · Environmentally friendly option
- Hire code 365605.

ARRANGE A PRODUCT DEMO ON: 0800 587 5121

CONTACT MEP HIRE

T: 0800 587 5121

E: hire@mephire.co.uk W: www.mephire.co.uk

